

Influence of Moisture Content on the Strength of Thermoplastic Reinforced Resins at Cryogenic Temperatures

Jordi Renart, Jordi Llobet, Edwin Meulman, Mayerlin Salgado, Albert Turon
SUSMATx, Girona 06.09.2024



NOVEL LOW-PRESSURE CRYOGENIC LIQUID HYDROGEN STORAGE FOR AVIATION



overleaf-project.eu



info@overleaf-project.eu




[@overleaf_eu](https://twitter.com/overleaf_eu)

Who we are



Funded by the European Union. Views and opinions expressed are however those of the author(s) only and do not necessarily reflect those of the European Union or CINEA. Neither the European Union nor the granting authority can be held responsible for them.

A 95 kg tank prototype will be tested in environmental conditions close to real operating ones



Inner thermoplastic composite tank

Specifications:

- LH2 storage at 20K
- Inner tank does not sustain pressure (external tank)
- There are only thermal stresses
- Additive manufacturing (3D Printing)
- Thermoplastic resin
- Avoid leakage

Motivation:

- During service, the material will absorb moisture
- How this moisture affects to the material strength?
- Does it depend on the porosity of the material?

Objective:

- Which is the influence of moisture content on the strength of the material?

Methodology

Material candidates



Porosity



Conditioning



Testing



Methodology

Material candidates



Porosity



Conditioning



Testing

PA11_BESNO_CNT4: PA11 Rilsan® BESNO 23 TL4 CC resin + 4%w CNT
PA11_BESNO_BF20: PA11 Rilsan® BESNO 23 TL4 CC resin + 20%w Basalt fibre
PA11_CLEARG820_BF20: PA11 Rilsan® CLEAR G820 + 20%w Basalt fibre
PEKK_BF20: PEKK KEPSAN® 6003 + 20%w Basalt fibre



Resin provider



Filament manufacturing



Specimen additive manufacturing

Methodology

Material candidates



Porosity



Conditioning



Testing

Acid digestion (EN 2564)


The resin is eliminated by immersing the specimen in pure H₂SO₄ at 160°C. Then the fibres are cleaned, filtered and dehydrated with acetone 100%. Finally, the fibres are dried at 120°C.

Calcination (ISO 1172)

The resin is eliminated by calcination at 625°C during 6 hours

Scanning Electron Microscopy, SEM (no standard)

Only used for porosity content. Useful when reinforcements are organic.



Methodology

Material candidates



Porosity



Conditioning



Testing

Baseline = Conditioning + Test at RT (23°C):

RTA: Ambient (23°C/50% RH) + Test

Conditioning + Immersion in LN2 (77K during 10min) + Test at RT (23°C):

RTLN: Ambient (23°C/50% RH) + Immersion in LN2 + Test (RTLN = RTA + Immersion)

RTDLN: Dry (80°C during 8h) + Immersion in LN2 + Test

RTWLN: Wet (70°C/85% RH) + Immersion in LN2 + Test

Methodology

Material candidates



Porosity



Conditioning




Testing

Test of dog bone specimens:

- Printing direction XZ-X
- Perpendicular to the printing direction XZ-Z

Printing of a vertical panel in the XZ plane. X is the printing direction.



Methodology

Material candidates



Porosity



Conditioning






Testing

Test of dog bone specimens:

- Printing direction XZ-X
- Perpendicular to the printing direction XZ-Z

Tensile tests according to ISO527-4 standard

- 1BA specimens:
- Tests at RT
- Before the tests the specimens were LN2 immersed during 10min



Results > Porosity

| Material | Fibre weight content (%) | Resin weight content (%) | Porosity content (%) | | |
|---------------------|--------------------------|--------------------------|----------------------|----------------|-------------|
| | | | Microscopy | Acid digestion | Calcination |
| PA11_BESNO_CNT4 | - | - | 0.2 | - | - |
| PA11_BESNO_BF20 | 19.1 | 80.9 | 0.8 | 0.4 | 0.3 |
| PA11_CLEARG820_BF20 | 19.1 | 80.9 | 6.9 | 5.8 | 6.1 |
| PEKK_BF20 | 19.1 | 80.9 | 16.3 | 11 | 11.1 |



- PEKK: highest values of porosity
- PA11 Besno®: lowest values of porosity
- SEM allows to obtain values of porosity even in organic reinforcements or CNT

Results > Moisture Content

| Material | Moisture content (%w) | |
|---------------------|-----------------------|-------------|
| | RTLN / RTA (Ambient) | RTWLN (Wet) |
| PA 11_BESNO_CNT4 | 0.98 | 1.56 |
| PA 11_BESNO_BF20 | 0.63 | 1.36 |
| PA 11_CLEAR820_BF20 | 0.80 | 1.78 |
| PEKK_BF20 | 0.33 | 0.64 |



RTDLN Dry specimens: 0.00% of moisture

Results > Tensile tests > Conditioning + Immersion + Test



Results > Tensile tests > Conditioning + Immersion + Test



PA11_BESNO_BF20: RTA and RTLN



- RTA and RTLN have the same moisture content (0.63%), the immersion in LN2 slightly reduces the strength value in XZ-X and XZ-Z



Results > Tensile tests > Conditioning + Immersion + Test

PA11_BESNO_BF20





- PA11_BESNO_BF20 strength is affected by moisture content + LN2 immersion

Results > Tensile tests > Conditioning + Immersion + Test





Results > Tensile tests > Conditioning + Immersion + Test

PEKK_BF20





- PEKK_BF strength is not affected by moisture content + LN2 immersion, is the material with the highest porosity (11%).
- PEEK_BF20 has lowest moisture content (0.33% and 0.64%) compared to the other candidates.

Results > Tensile tests > Conditioning + Immersion + Test



Results > Tensile tests > Conditioning + Immersion + Test

PA11 candidates in XZ-Z direction:



- The strength of both PA11 candidates is affected by Moisture + LN2 immersion
- Despite having a higher moisture content, PA11_CLEARG820_BF20 is less affected than PA11_BESNO_BF20.
- PA11_CLEARG820_BF20 has higher porosity (6%) than PA11_BESNO_BF20 (0.3%).

Preliminary observations

From the material candidates analysed and after the conditioning + immersion in LN2 we observe that:

- **Candidates with the highest moisture content** (PA11 based resin candidates) experience a **reduction in strength as humidity increases** and after the immersion in LN2.
- For Basalt Fiber reinforced candidates **with a higher porosity exhibit less reduction in strength** as humidity increases.
- This strength reduction depends on the **humidity content** but also on **the fibre/resin**, and the **printing direction**.



<http://amade.udg.edu>

testlab.amade@udg.edu



Part of:

